

Tool Overview

Icon	Tool
	Select Features Select features within a specific region on the map.
	Measure Measure the distance of a line or the surface of an area between two points.
	Marker Add a Marker location to the map with notes to identify a point of interest.
	Profiles Visualize the profiles of the seabed floor and cables or pipelines as a line graph.
	Burial (Difference) Assessment Calculates the (difference in) burial depth of a cable/pipeline relative to a single or combination of bathymetry layers. The result creates a new layer that shows the status as a color on top of the line.
	Calculate • Allows calculations to be made between two overlapping bathymetry layers or a fixed reference level. The result creates a new layer. • Allows calculation of the volume difference between bathymetry layers or against a reference level within defined polygon areas
	Display Options Adjust how raster layers are visualized on the map.
	3D View Load a 3D visualization of a raster file and view/rotate/zoom it in a new browser tab.
	Export Map Create a downloadable PDF chart.

Revision #13

Created 2026-02-19 13:54:01 UTC by Simon Prosser

Updated 2026-05-13 05:43:48 UTC by Simon Prosser